

NCR DECISION MATE V

**ANSCHLUSS AN DECISION NET
(K600)**

Die beiliegenden Seiten zeigen Ihnen, wie Sie diese Leistungserweiterung an Ihren NCR DECISION MATE V anschließen können. Bitte ordnen Sie diese Beschreibung in Ihre Bedienungsanleitung für den NCR DECISION MATE V ein.

NCR ist ständig bemüht, die Produkte im Zuge der Entwicklung von Technologie, Bauteilen, Soft- und Firmware dem neuesten Stand anzupassen. NCR behält sich deshalb das Recht vor, Spezifikationen ohne vorherige Ankündigung zu ändern. Nicht alle hier beschriebenen Leistungen werden von NCR in allen Teilen der Welt vertrieben. Nähere Informationen bezüglich eventueller Einschränkungen oder Erweiterungen sowie den aktuellen Stand erfahren Sie von Ihrem Händler oder der nächstgelegenen NCR-Geschäftsstelle.

Um den Schutz des Benutzers sicherzustellen, ist beim Anschluß von nicht durch NCR hergestellten Geräten darauf zu achten, daß diese ebenfalls die VDE-Vorschriften einhalten.

ANSCHLUSS AN DECISION NET (K600-V001)

1. Stellen Sie die an diesem Adapter befindlichen Schalter anhand der untenstehenden Tabelle ein, um die Identifikationsnummer für die Verständigung mit Decision Net festzulegen.

Beispiel (Identifikationsnummer 9):

(Aus) 1

1	2	3	4	5	6


(Ein) 0

1	2	3	4	5	6

BEN.NR.		SCHALT.NR.					
HEX	DEC	1	2	3	4	5	6
0	0	0	0	0	0	0	0
1	1	1	0	0	0	0	0
2	2	0	1	0	0	0	0
3	3	1	1	0	0	0	0
4	4	0	0	1	0	0	0
5	5	1	0	1	0	0	0
6	6	0	1	1	0	0	0
7	7	1	1	1	0	0	0
8	8	0	0	0	1	0	0
9	9	1	0	0	1	0	0
A	10	0	1	0	1	0	0
B	11	1	1	0	1	0	0
C	12	0	0	1	1	0	0
D	13	1	0	1	1	0	0
E	14	0	1	1	1	0	0
F	15	1	1	1	1	0	0
10	16	0	0	0	0	1	0
11	17	1	0	0	0	1	0
12	18	0	1	0	0	1	0
13	19	1	1	0	0	1	0
14	20	0	0	1	0	1	0
15	21	1	0	1	0	1	0
16	22	0	1	1	0	1	0
17	23	1	1	1	0	1	0
18	24	0	0	0	1	1	0
19	25	1	0	0	1	1	0
1A	26	0	1	0	1	1	0
1B	27	1	1	0	1	1	0
1C	28	0	0	1	1	1	0
1D	29	1	0	1	1	1	0
1E	30	0	1	1	1	1	0
1F	31	1	1	1	1	1	0

BEN.NR.		SCHALT.NR.					
HEX	DEC	1	2	3	4	5	6
20	32	0	0	0	0	0	1
21	33	1	0	0	0	0	1
22	34	0	1	0	0	0	1
23	35	1	1	0	0	0	1
24	36	0	0	1	0	0	1
25	37	1	0	1	0	0	1
26	38	0	1	1	0	0	1
27	39	1	1	1	0	0	1
28	40	0	0	0	1	0	1
29	41	1	0	0	1	0	1
2A	42	0	1	0	1	0	1
2B	43	1	1	0	1	0	1
2C	44	0	0	1	1	0	1
2D	45	1	0	1	1	0	1
2E	46	0	1	1	1	0	1
2F	47	1	1	1	1	0	1
30	48	0	0	0	0	1	1
31	49	1	0	0	0	1	1
32	50	0	1	0	0	1	1
33	51	1	1	0	0	1	1
34	52	0	0	1	0	1	1
35	53	1	0	1	0	1	1
36	54	0	1	1	0	1	1
37	55	1	1	1	0	1	1
38	56	0	0	0	1	1	1
39	57	1	0	0	1	1	1
3A	58	0	1	0	1	1	1
3B	59	1	1	0	1	1	1
3C	60	0	0	1	1	1	1
3D	61	1	0	1	1	1	1
3E	62	0	1	1	1	1	1
3F	63	1	1	1	1	1	1

2. Setzen Sie den Adapter in eine der Steckfassungen 2...6 ein, die sich an der Rückseite Ihres NCR DECISION MATE V befinden. Dieser Adapter benötigt zwei nebeneinanderliegende Fassungen.



3. Schließen Sie den am Kabelende vorhandenen Stecker an die dafür vorgesehene Buchse des Decision-Net-Systems an.

HINWEIS: Die Leistungsfähigkeit von Decision Net wird in dem dazugehörigen Handbuch beschrieben.

KIT INSTALLATION
for
DECISION NET INTERFACE
(K600-V001)

The attached pages provide information for installing this kit into an NCR DECISION MATE V. These pages should be filed in your NCR DECISION MATE V User Information Manual.

**FEDERAL COMMUNICATIONS COMMISSION (FCC)
RADIO FREQUENCY INTERFERENCE STATEMENT**

WARNING

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Information to User

This equipment must be installed and used in strict accordance with the manufacturer's instructions. However, there is no guarantee that interference to radio communications will not occur in a particular commercial installation. If this equipment does cause interference, which can be determined by turning the equipment off and on, the user is encouraged to consult an NCR service representative immediately.

The NCR Corporation (NCR) is not responsible for any radio or television interference caused by unauthorized modification of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by NCR. The correction of interferences caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

Please note that this unit is classified as an FCC Class A Product.

If this unit is used with any FCC Class B certified unit, the total product is degraded to FCC Class A.

It is the policy of NCR Corporation to improve products as new technology, components, software, and firmware become available. NCR Corporation, therefore, reserves the right to change specifications without prior notice.


All features, functions, and operations described herein may not be marketed by NCR in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult your NCR representative or NCR office for information that is applicable and current.

KIT INSTALLATION

DECISION NET INTERFACE
(K600-V001)

1. Set the switch assembly, located on the bottom of the Decision Net Interface, to the desired configuration. The possible settings are shown below:

DECISION MATE V TRANSPORTER SWITCHES



REQUESTER ID		SWITCH SETTINGS					
HEX	DEC	1	2	4	8	16	32


0	0	0	0	0	0	0	0
1	1	1	0	0	0	0	0
2	2	0	1	0	0	0	0
3	3	1	1	0	0	0	0
4	4	0	0	1	0	0	0
5	5	1	0	1	0	0	0
6	6	0	1	1	0	0	0
7	7	1	1	1	0	0	0
8	8	0	0	0	1	0	0
9	9	1	0	0	1	0	0
A	10	0	1	0	1	0	0
B	11	1	1	0	1	0	0
C	12	0	0	1	1	0	0
D	13	1	0	1	1	0	0
E	14	0	1	1	1	0	0
F	15	1	1	1	1	0	0
10	16	0	0	0	0	1	0
11	17	1	0	0	0	1	0
12	18	0	1	0	0	1	0
13	19	1	1	0	0	1	0
14	20	0	0	1	0	1	0
15	21	1	0	1	0	1	0
16	22	0	1	1	0	1	0
17	23	1	1	1	0	1	0
18	24	0	0	0	1	1	0
19	25	1	0	0	1	1	0
1A	26	0	1	0	1	1	0
1B	27	1	1	0	1	1	0
1C	28	0	0	1	1	1	0
1D	29	1	0	1	1	1	0
1E	30	0	1	1	1	1	0
1F	31	1	1	1	1	1	0

REQUESTER ID		SWITCH SETTINGS					
HEX	DEC	1	2	4	8	16	32

20	32	0	0	0	0	0	1
21	33	1	0	0	0	0	1
22	34	0	1	0	0	0	1
23	35	1	1	0	0	0	1
24	36	0	0	1	0	0	1
25	37	1	0	1	0	0	1
26	38	0	1	1	0	0	1
27	39	1	1	1	0	0	1
28	40	0	0	0	1	0	1
29	41	1	0	0	1	0	1
2A	42	0	1	0	1	0	1
2B	43	1	1	0	1	0	1
2C	44	0	0	1	1	0	1
2D	45	1	0	1	1	0	1
2E	46	0	1	1	1	0	1
2F	47	1	1	1	1	0	1
30	48	0	0	0	0	1	1
31	49	1	0	0	0	1	1
32	50	0	1	0	0	1	1
33	51	1	1	0	0	1	1
34	52	0	0	1	0	1	1
35	53	1	0	1	0	1	1
36	54	0	1	1	0	1	1
37	55	1	1	1	0	1	1
38	56	0	0	0	1	1	1
39	57	1	0	0	1	1	1
3A	58	0	1	0	1	1	1
3B	59	1	1	0	1	1	1
3C	60	0	0	1	1	1	1
3D	61	1	0	1	1	1	1
3E	62	0	1	1	1	1	1
3F	63	1	1	1	1	1	1

2. Install the interface into a vacant slot at the rear of the NCR DECISION MATE V (slots 2 to 6 may be used).

NOTE: This interface is double the normal width and occupies two slot positions.



3. Fit the plug into an adjacent tap-box in the installed network.

NOTE: For more information you should refer to the Decision Net documentation.